

Figure 15.6 Illustration of a bus in which a single set of lines is used for both addresses and data. Using one set of lines helps reduce cost.