

Wire 1	Wire 2	Meaning
0	0	Reset before starting a new bit
0	1	Transfer a 0 bit
1	0	Transfer a 1 bit
1	1	Undefined (not used)

Figure 2.24 Meaning of signals on two wires when clockless logic is used to transfer bits from one chip to another.