



Figure 22.6 Example of a chip-level architecture that shows the major internal components of a Netronome network processor. Access units provide connections outside the chip.