

```
push X  
push 7  
add  
pop X
```

Figure 7.1 An example of instructions used on a stack computer to add seven to a variable X. The architecture is known as a zero-address architecture because the operands for an instruction such as *add* are found on the stack.