



Figure 22.3 Example of a system-level architecture that shows the physical interconnections in a PC that uses two controller chips. Components that require the highest speeds attach to the *Northbridge* controller.