



Figure 8.11 An example instruction that simultaneously continues an ALU operation and loads the value from register seven into operand hardware unit one. Horizontal microcode makes parallelism easy to specify.